

25X1



0191 DA

PRE DESIGN REVIEW

SCOPE

- Establish feasibility of HILS approach
- Approve light pack design concepts
- Approve tracking system design concepts
- Investigate trade offs presented

RESULT

- Establish configuration for final design

Declassification Review by NGA/DoD

25X1

- 2 -

STUDY PHASE - OPTICAL

HAS ACCOMPLISHED

BACKGROUND LUMINANCE
SUBSTITUTION OF STRAIGHT FLUORESCENT LAMPS
RETENTION OF ELECTRICAL MASKING
USE OF TUNGSTEN AS LIGHT SPOT SOURCE
COLOR BALANCE AND RENDERING
CONFIGURATION OF LIGHT PACK

THREE LAMPS HAVE BEEN REVIEWED

TUNGSTEN - TRU FOCUS TYPE (HALOGEN)
MARC 300
XENON ARC
 INBOARD
 OUTBOARD

PREFERENCE DIRECTED TO TUNGSTEN LIGHT PACK

LOWER OPERATING COST
MINIMUM RECURRING COST
EASE IN REPLACEMENT
MINIMUM ELECTRIC INPUT POWER
SAFETY
SIMPLEST CONFIGURATION
EXTRA HIGH COLOR RENDERING
MINIMUM POWER REQUIREMENTS

SYSTEM IS VERSATILE

LUMINANCE CAN BE INCREASED BY
 VOLTAGE INCREASE AS FOR B/W OR COLOR FILM
 COLOR FILTERS REMOVAL FOR B/W FILM
 COLLIMATOR SUBSTITUTION TO REDUCE SPOT SIZE
 VIEWING SCREEN GAIN CHANGE

25X1



BACKGROUND LIGHTING GOALS

- 1) 2000 FT. LAMBERTS MINIMUM
- 2) UNIFORMITY COMPARABLE TO EXISTING MLT
EXCLUDING CONTRIBUTION OF HILS
- 3) RETAIN ELECTRIC MASKING CONTROL

25X1



BACKGROUND LIGHTING STUDY RESULTS

STUDIED TWO APPROACHES


- 1) Curved lamps
- 2) Shortened straight lamps

SELECTED SHORTENED STRAIGHT LAMPS - Fulfills goals with TR-70 screen

- 1) 2000 ft. lamberts at center measured with GFE Weston meter
- 2) Retain intensity control on background lighting
- 3) Background fluorescents provide along center a luminance distribution with minimum of 2000 ft. lamberts at 4" from center edge and does not drop below 45% 1/2" from center edge as measured with GFP Weston and excluding effect of HILS pack.

SOLUTION - See Sketch 1

- 1) Short straight lamps of identical phosphor and diameter as existing MLT.
- 2) High reflecting mirror at one end of lamps center edge of lamp cavity or light tray tilted 55° up from horizontal.



CONFIG. 1—H.I.L.S. BACKGROUND LAMP

25X1



LIGHT PACK STUDY GOALS

- . 25,000 FOOT LAMBERTS
- . 20% MAXIMUM VARIATION OVER AREA WITHIN 2-3/4" SPOT
- . 2-3/4" SPOT
- . CORRELATED COLOR TEMPERATURE 5000°K \pm 500
- . CRI MINIMUM OF 70
- . \bar{x} , \bar{y} CHROMATICITY AIM POINTS
- . INTENSITY CONTROL CONTINUOUSLY VARIABLE 1500-25,000 FT. LAMBERTS
- . HEAT AT FILM OF 2.0 DENSITY 30°F ABOVE AMBIENT AT 25,000 FT. LAMBERTS
- . 8" \times 15" CENTRAL AREA
- . FILL NUMERICAL APERTURE EFFECTIVELY

25X1


- 7 -


SUMMARY TUNGSTEN LIGHT PACK

VIEWING SURFACE DIFFUSER	Polacoat TR-70	
LAMP	ELH 300 watt, 120 volt rated, 110 operating volts	
LIFE	Nominal 100 hours at operating volts, \$.09/hour operating cost	
REPLACEMENT	Snap in	
LUMINANCE	25,000 ft. lamberts peak color corrected	
INTENSITY CONTROL	To 1500 ft. lamberts color corrected iris control	
SPOT SIZE	Overall 3" diameter	
UNIFORMITY	25% over 2-1/2" effective diameter 30% over 2-3/4" effective diameter	
COLOR	4800°K nominal - minimum 4500°K	
°K		
Color Rendering Index	80+	
Chromaticity Air Points	x = .350, y = .365 nominal	
IRRADIANCE	At 10" height 2×10^{-3} watt/cm ²	
FILM TEMPERATURE	At 25,000 ft. lamberts	
	Spot only	22°F above ambient
	Surround	maximum 30°F above ambient
LUMINANCE	Through B&L microscope, 10x ocular, 3x ASR, 3x zoom = 560 ft. lamberts approximate	
VERSATILITY	For black and white film	
	Remove color filter, luminance,	120,000 ft
	plus	
	Substitute higher gain diffuser	210,000 fl
	or	
	Retain color correction and	45,000 fl
	substitute higher gain diffuser	corrected
	Max. luminance possible thru	4,600 fl
	microscope (at 210,000 fl)	


ILLEGIB

CONFIGURATION- HIGH INTENSITY LIGHT PACK






RANGE AND COLOR CORRECTION ETL LAMPS (200 WATTS)



-11-

POLAR PLOT OF LUMINANCE VS ANGLE FROM NORMAL



25X1

25X1



TECHNICAL SUMMARY OF XENON ARC PACK

ILLEGIB



ILLEGIB

(2) Lamp ILC 300 watt
Sapphire envelope

(2) Lamp PEK 500 watt
Ozone free quartz

(2) Power Supply - 400 watt
18x18x9", 90 lbs. each

(2) Power Supply - 600 watt
24x12x12", 120 lbs. each

(2) Igniters - 5-1/2x5-1/2x4"
8 lbs. each, 20KV

(2) Igniters - 5-1/2x5-1/2x4"
8 lbs. each, 30 KV

Lamp length < 2-1/2"

Lamp length 5.8"

Life - 500 hours, 40¢/hr - 20¢/hr

Life - 1000 hours, 15¢/hr - 10¢/hr.

Intensity - 750 cdles.

Intensity - 1600 cdles.

Special development req'd (Ozone gas seal)

Intensity control - Neutral density disk

Neutral density disk

Calculated Performance

Luminance

Peak 14,000 ft. lamb.

30,000 ft. lamb.

Uniformity 30%

20%

Color

Temperature 5500°K

5500°K


CRI 80+


80+

Slow flicker from arc wandering


ILLEGIB

ILLEGIB





XENON ARC - OUTBOARD CONFIG.



CORRECTED XENON ARC LAMPS (TYPICAL)

ILLEGIB

SUMMARY LIGHT PACK

	<u>TUNGSTEN</u>	<u>ARC OUTBOARD</u>
LAMP	300 watt	500 watt
LIFE	100 hours	1000 hours
LUMINANCE	25,000 fl	30,000 fl
MAX. LUMINANCE (Uncorrected)	120,000 fl	55,000 fl
COLOR TEMPERATURE	4800°K	5500°K
TOTAL SIZE (per table)	< 1 ft ³	~ 5 ft ³
WEIGHT	< 10 lb.	~ 250 lbs.
POWER	~ 600 w	~ 1200 w

OPERATING COST (one side)

LAMP COST

POWER SUPPLY

OPTICS

25X1

ILLEGIB

Light Pack Components for Prototype

25X1

Power Supply
and Optics

ILLEGIB

25X1



CONFIGURATION GOALS

HILS COVERAGE - 8" x 15"

HILS TO TRACK MICROSCOPE RHOMBOIDS

EACH HILS TO BE USABLE ALONE

MANUAL POSITION CONTROL FOR EACH HILS

SEPARATE ON/OFF & DIMMING CONTROLS FOR EACH HILS

NO CHANGE IN VIEWING SURFACE HEIGHT

MINIMUM SHADOWING FROM HILS

PARKING ABILITY

25X1



CONFIGURATION STUDY PHASE RESULTS

HILS COVERAGE	8" x 13"
MOTION SYSTEM	DC gear head motors capable of driving the HILS in X and Y from 0 to 1"/sec. Will operate normally when table is tilted.
TRACKING SYSTEM	Positive position servo to the bridge. Position transducers will be located on the bridge and each HILS.
MANUAL CONTROL	X and Y position potentiometers will be provided for each HILS.
PARKING	A Park/Track switch for each HILS will be provided. The Park position will move the HILS to the Rear Center of the viewing surface.
POWER	An ON/OFF switch will be provided for each HILS. The power switch will also control the fan for each HILS.

25X1




COOLING GOALS

FILM PLANE $\leq 110^{\circ}\text{F}$ or 30°F above ambient

TEST CONDITION 66% of glass covered by 2.0 density film

25X1



STUDY PHASE RESULTS

COOLING

FILM TEMPERATURE - measured in center of HILS Spot
operating at 25,000 ft. lamberts with background at
ft. lamberts

22°F Above Ambient



TEMPERATURE OF SURROUNDING FILM -
measured as above

30°F Above Ambient max.

COOLING METHOD - exhaust fan for each HILS, approximately 8 CFM per HILS.

LAMP BASE TEMPERATURE - (Safe operating temperature = 300°C) 230°C

FILM TEMPERATURE AT INCREASED LUMINANCE LEVELS - see chart.



FILM TEMP. RISE ABOVE AMBIENT

02 -

25X1



CONCLUSIONS

Specification Conformance

- Tungsten light pack meets or exceeds all specifications except uniformity of spot.
- Uniformity worse case is 30% at edge of spot only.


Tungsten Light Pack

- Less costly than arc source
- Smaller than arc source
- Requires no external power supply
- Lower power consumption than arc source
- Safer than arc source.

RECOMMENDATION

Tungsten light pack with ELH 300 watt lamp, with electric servo controlled X,Y drive and tracking system.

H.I.L.S. CONFIGURATION



- 23 -

25X1



PERFORMANCE

TUNGSTEN LIGHT PACK THROUGH MICROSCOPE

Numerical Aperture Illumination Comparison
 3x ASR, NA .206, 10x Ocular, TR-70 Diffuser over HILS

	Luminance	Luminance	
	Target	3x Zoom	Effectiveness
HILS	23,000	500	
MLT	2,850	70	
Ratio $\frac{\text{HILS}}{\text{MLT}}$	8.0	7.2	.90
		2.0 Zoom	
	22,000	500	
	2,850	69	
Ratio	7.8	7.3	.94
		0.7 Zoom	
	22,500	530	
	2,800	70	
Ratio	8.0	7.6	.95

Luminance Transmission of Microscope
 3x ASR, 3x Zoom, 10x Ocular, MLT Source
 82 Ft. Lamberts through microscope
 3350 Ft. Lamberts MLT target

$$T = 2.4 \times 10^{-2}$$

Binocular viewing through one rhomboid

25X1

Approved For Release 2005/02/17 : CIA-RDP78B05171A000400020029-0

Next 1 Page(s) In Document Exempt

Approved For Release 2005/02/17 : CIA-RDP78B05171A000400020029-0